Web stiffeners required.

G5h STEICOjoist to STEICOjoist connection (2 Ply)

Backer blocks to be fitted as detail G7. Web stiffeners to be fitted as detail G6. Joist hanger installed in line with 2 Ply i-joist connected using manufacturers guidance. Cullen® I-Clips or Simpson Strong-Tie® MJC in line with manufacturers recommendations.

Backer blocks required.